



NEWS FROM LOTUS / EAST



DUTCHESS AUTO COMPANY, IMPORTER, MILLERTON, N. Y. 914-789-4425 • LOTUS/EAST, INC., DISTRIBUTORS, BOX 394. SALISBURY, CONN.


SERVICE BULLETIN #4

(Not Dated)

LOTUS EUROPA
Gearbox (Transmission)

Commencing at Unit No. 46/0267, a new gearbox (Part # A46F723) with revised gate pattern has been fitted. The gate pattern refers to the gearshift lever.

If reference is made to the identification tag at the rear end of the gearbox, adjacent to the selector shaft, this will show which type is fitted (either 336/08 or 356/26), see below.



Electrical System

All dealers are reminded that this model is equipped with a **NEGATIVE** earth battery and alternator. Any subsequent electric equipment which maybe fitted **MUST** be of the negative earth type, particularly any equipment having transistors, i.e., radio.

NEVER disconnect the battery when the engine is running, otherwise damage could be caused to the alternator and rectifier. **NEVER** connect a battery charger to the battery without first disconnecting the cables. When using electric arc welding equipment, **ALWAYS** disconnect the battery cables, disconnect all cables from the alternator and all cables from the rectifier. When refitting cables ensure that all connections are made correctly.