




**ALUMINUM SPACER**  
(4) REQUIRED  
SPACERS TO BE USED ON EACH SIDE OF OUTER SPHERICAL BEARING AT ATTACHMENT POINT TO HUB CARRIER



**END FITTING**  
(4) REQUIRED



SPACERS TO BE USED ON EACH SIDE OF OUTER SPHERICAL BEARING AT ATTACHMENT POINT TO HUB CARRIER

